

Installing Your Cisco SPA5XX Phone

You will be provided the following in your package to be used to install your new phone(s).

1. The phone base



2. Phone hand set and hand set cord



3. Phone stand



4. Two Ethernet cables.



Installing Your Cisco SPA5XX Phone

5. Power adapter (if no power over Ethernet switch is being used).



Flip your phone base (1) over and you will see the below ports. Follow the instructions for each port to get your phone up and running.



Plug your power adapter (5) into this port on the back of your phone. Run the other end to a power outlet.

If you will be running your PC through your phone and do not have a separate ethernet jack. Plug the Ethernet cord (4) into the PC port on the phone, run the other end back to the NIC card of your computer.

Plug the other Ethernet (4) cord into the SW port on your phone and run the other end back to your wall jack, switch, or router LAN port(s).

Plug one end of the hand set cord (2) into the HAC port on your phone. Run the other end of the hand set cord into your hand set (2).