





Cisco 7800 Series

TRANSFERRING CALLS

With Announcement - With the caller on the line, press  + Dial Ext - Recipient answers, announce the call:



- To complete the transfer, press  or the **Transfer** softkey.
- To cancel the transfer, **press Cancel**. This will end the call to the recipient and reconnect you with the original caller.

Without announcement – With the caller on the line, press the  softkey, press **BlindXfer** + Dial Ext (or telephone number if external)

Directly to Voice Mail – With the caller on the line, press  + **VM Prefix*** + Dial Ext + **Transfer** softkey.

** VM Prefix is either 03 or 5 depending on platform.*

CONFERENCE CALLING (3-Way Calling)

With the first person on the phone press  and dial your next party (first caller is on hold). When the second party answers, press  again to bring all three together.

Press **Join** softkey to remove yourself from the call and keep the other two connected.

CALL PARK

Parking Calls – With the caller on the line, press one of the available park buttons on the phone.

Retrieving Parked Calls – Press the blinking Park button associated with your call.

CALL FORWARDING


To Enable Call Forwarding:

Press '**Forward**' softkey.
Enter extension or telephone number (for external calls)
You'll receive a confirmation tone.



To Disable Call Forwarding:

Press **Clr Fwd** softkey.

RECENT CALLS

Press **Applications** 
Select **Recents**
Select a line to view

PUT A CALL ON HOLD

Press **Hold** / 
To resume a held call, press **Hold** /  again


PAGING (if applicable)

Dial assigned paging extension for your system.

INTERCOM (if applicable)

Dial **08** or **intercom softkey** (if available) + Ext
* You may have a soft key or dedicated line key for Intercom depending on platform/ configuration.

CHANGE THE RINGTONE

Press **Applications** 
Select **User Preferences > Ringtone**
Select a line
Scroll through the list of ringtones and press **Play** to hear a sample.
Press **Set** and **Apply** to save selection.

Your Phone



Your Phone

Cisco IP Phone 7841 shown.

- ① Incoming call or voicemail indicator
- ② Line and feature buttons
- ③ Softkeys
- ④ Navigation (navigation ring and **Select** button)
- ⑤ Hold, Transfer, and Conference
- ⑥ Speakerphone, Headset, and Mute
- ⑦ Voicemail, Applications, and Directory
- ⑧ Volume

Line and Feature Buttons

Use line and feature buttons to view calls on a line, or access features such as Speed Dial.

Buttons illuminate to indicate status:

- Green, steady: Active call
- Green, flashing: Held call
- Amber, steady: Private line in use
- Amber, flashing: Incoming call
- Red, steady: Remote line in use
- Red, flashing: Remote line on hold